Issued: January 27, 2014 Revised: May 23, 2023



Technical Newsletter #31 4.1

Subject: Radiant heating systems recommendations

Mirage knows there are a lot of different radiant heating systems available on the market. Based on tests carried out by the Mirage R&D team to evaluate some of the systems in terms of risk regarding platforms and installation methods, this technical newsletter will review the recommendations Mirage has regarding the installation of a radiant heating system, the type of system that is allowed to install depending on the floor technology and installation method, and the exclusions.

Here are some general recommendations:

- Make sure to use adhesives recognized by the radiant heating system manufacturer's and by Mirage <u>Technical Newsletter #23</u>.
- Make sure the wood surface temperature never exceeds 80 °F (27 °C) and not vary from any point by more than 3 °F (2 °C).
- Mirage recommendations should never overpass the radiant heating system manufacturer's instructions.
- Make sure the radiant heating system has been tested and in operation for a week prior to the floor installation. The system temperature should be lowered during installation.

Please find below which type of system is allowed to be installed depending on the floor technology and installation method.

	Type of technologies and installation methods			
	Gluing	Floating*	Nailing**	
	mirage TruBalance	mirage TruBalance	mirage TruBalance	
	mirage TruBalance lite	mirage TruBalance lile	mirage TruBalance Lile	
	mirage Engineered		mirage Engineered	
Type of radiant heating systems	mirage	mirage		
Pipes or electric grid embedded in concrete (slab or thin layer of gypcrete/light concrete)	Yes	Yes	N/A	
Pipes in grooved wooden panels (not covered on top)	Yes	Yes	Please refer to the Technical Newsletter #36. method 4 with at least 2 beads.	
Uncovered pipes in grooved wooden panels with aluminum/metal plated	Yes	Yes	Please refer to the <u>Technical Newsletter #36</u> , method 4 with at least 2 beads.	

Continued on next page.

Issued: January 27, 2014 Revised: May 23, 2023

	Type of technologies and installation methods			
	Gluing	Floating*	Nailing**	
	mirage Trubalance	mirage Trubalance	mirage TruBalance	
	mirage TruBalance lile	mirage TruBalance lile	mirage Trubalance lite	
	mirage Engineered		mirage Engineered	
Type of radiant heat systems	mirage	mirage		
Pipes covered with dissipating aluminum/metal plates and/or wooden panels (also dissipating plates between pipes)	Yes	Yes	Please refer to the Technical Newsletter #36, method 4 with at least 2 beads.	
Pipes or electrical system fixed under the subfloor (in joist system)	Yes	Yes	Please refer to the Technical Newsletter #36, method 4 with at least 2 beads.	
Semi-conductive types of polymers or "heating mat" (all the surface of the panel/mat is heating)	Yes	Yes	N/A	
"Metal heating foil" not attached to subfloor	No	Yes	N/A	
Electrical wire system attached or not to a "neutral support"	Yes***	Yes	N/A	

^{*}Using a recommended membrane following <u>Technical Newsletter #20</u>, with TruBalance, TruBalance Lite or Lock product only.

Exclusions

Based on tests carried out by the Mirage R&D team regarding the performance of <u>Classic technology</u> <u>floors and all Hickory floors</u> over radiant heat, and based on the National Wood Flooring Association statement that radiant heating installations using denser species are less stable, **Mirage does not allow these products to be installed over this type of system.**

If you need more information or have any questions, please feel free to contact our Technical Service Department.

Mirage Technical Service Department 1-800-463-1303 technical@miragefloors.com

^{**}We understand that some system can be covered by a wood panel to allow nailing (even if embedded in concrete for example). Nailing installation is not preferred since it could lead to more floor movement and risk of system damage.

^{***}Wire diameter and spacing should lead to an 80% glue transfer to be a valid installation. Trowel and adhesive coverage could vary.